


COOKTOP PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2

(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)

30" GAS FREESTANDING
SELF CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1	9762998	Literature Parts Installation Instructions
	9757142	Anti-Tip Template English/Spanish
	9757143	English/French
	W10162213	Owners Manual
	W10116296	Tech Sheet
	9762761	Safer Cooking Tips
2		Cap, Burner Left Front
	3191904	Black
	3191905	Grey
	8273345	Espresso R. Front, L. Rear
	3191901	Black
	3191903	Grey
	8273344	Espresso Right Rear
	3191898	Black
	3191899	Grey
	8273343	Espresso


Illus. No.	Part No.	DESCRIPTION
3		Burner
	4455981	Left Front
	4455980	R. Front, L. Rear
	4455979	Right Rear
4		Cooktop
	8272251	White
	8272743	Biscuit
	8272253	Black
5		Panel, Manifold
	8523855	Black
	8523854	White
	8523856	Biscuit

Illus. No.	Part No.	DESCRIPTION
6		Knob, Control (3)
	8273103	Black
	8273104	White
	8273106	Biscuit
7		Knob, Powerburner
	8273111	Black
	8273112	White
	8273114	Biscuit
8		Grate, Burner (4)
	8522851	Black
	8522850	Grey
	8522853	Espresso
9	3400701	Screw
10	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	W10009080	Endcap, Left Hand Black
	W10009040	White
	W10009060	Biscuit
	W10009090	Endcap, Right Hand Black
	W10009050	White
	W10009070	Biscuit


Illus. No.	Part No.	DESCRIPTION
2	9762093	Panel, Control Black
	9762091	White
	9762092	Biscuit
	9762094	Stnls,Univ Slvr
3	9758080	Module, Spark
4	9762095	Brkt-Mntg, Console
5	8523412	Bracket, Support
6	9756301	Cover, Upper
7	8053910	Shield, Heat
8	8273132	Cover, Lower

Illus. No.	Part No.	DESCRIPTION
9	3196169	Screw
10	W10108190	Control, Range Black
	W10108180	White
	W10108200	Biscuit
11	3196178	Screw
12	9757609	Badge
13	9762726	Brkt-Mntg, DSI
14	8273564	Clip
15	9762078	Brkt, Mntg EOC
16	8053505	Heat-Shield, Lower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)

Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
	8273701	Small (1)
3		Tubing, Burner W/Orifice
	8273693	Left Front
	8273698	Left Rear
	8273695	Right Front
	8273697	Right Rear
4	8523402	Tubing (Manifold to Regulator)
5	8523406	Harness, Igniter (W/Switches)
6	8523793	Electrode (4)
7	9762230	Pipe, Manifold
8		Valve
	9757218	LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	8053970	Spreader, Flame (Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16		Igniter
	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler Fitting To Valve)
18	3186489	Fitting, Broiler
19		Orifice, Burner
	8273064	Left Front
	8273065	Right Front
	8273066	Left Rear
	8273067	Right Rear
20	8053262	Spreader, Flame (Broiler)
21	3196265	Screw
22	3196176	Screw
23	3196385	Screw
24	3400016	Screw


Following Parts Not Illustrated

8523420 Spuds, LP Gas
(Kit of 4)

CHASSIS PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2

(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10153186	Flue Box	17	9757098	Back, Main	34	3196152	Screw
2	8272747	Shield, Flue	18	8522416	Seal, Oven	35		Screw
3	8273036	Burner Box	19	8053971	Brace, Main Back		3196166	White
4		Panel, Side (2)	20		Retainer, Insul.		8281194	Biscuit
	8053830	White-Textured		9761449	Left Hand		3196168	Black
	8272519	Biscuit-Textured		9761448	Right Hand	36	W10031780	Screw
	8053832	Black-Textured	21	3196576	Clip, Panel (6)	37	3196179	Screw
5	8523249	Brkt, Manifold Mtg	22	9757891	Cord, Power	38	3196177	Screw
6	W10067840	Screw	23	9760407	Brkt - Hinge	39	3196168	Screw
7	3196037	Foot, Front (2)	24	9757262	Switch, Door	40	9757239	Rod - Door Switch, Rear Mount
8	W10058460	Foot, Rear (2)	25	3196701	Light Socket Assy	41	3196560	Screw
9	3195097	Bottom, Oven	26	311255	Bulb, Oven Light			
10	W10131826	Sensor, Oven	27	9761013	Latch, Door			
11	8053967	Baffle, Burner	28	W10078370	Rod, Latch			
12	8053969	Shield, Heat	29	W10107820	Latch-Mtr			
13	8053968	Shield, Lower	30	W10114344	Glide, Drawer			
14	9760314	Rail, Base (2)	31	9761490	Insulation		8524099	Insulation, Wrap
15	9761517	Clip,Door Mntg(2)	32	9761512	Clip, Mounting		8272614	Insulation, Back
16	9758701	Spacer, Door	33	3196178	Screw		8272613	Insulation, Vent

INSULATION

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Top	9	9761357	Retainer, Insul.	13	3196160	Screw
	9762391	Black	10		Hinge, Door	14	3196165	Screw
	9761975	White		9761493	Wht,Blk,Bsct,US	15	3196794	Bracket, Window(2)
	9761976	Biscuit		9761496	Stainless Model	16		Trim, Bottom
	9762394	Stainless Steel	11		Glass, Outer Door		8523177	Black
	W10067560	Universal Silver		W10075990	Black		8523175	White
2	3196164	Screw		W10075980	White		8523178	Biscuit
3		Handle, Door		W10076000	Biscuit		8523180	Stainless Model
	9761983	Black		9756435	Stnls & Univ Slvr		W10067550	Universal Silver
	9761982	White	12		Trim, Door Side	17	W10031780	Screw
	9761984	Biscuit			Left Hand	18	W10113759	Strap, Door
	9761985	Universal Silver		8523171	Black			
4	9761344	Liner, Door		8523172	White			
5	W10031790	Screw		8523173	Biscuit			
6	9758162	Glass, Inner (2)		W10113926	Universal Silver			
7	3186289	Frame, Glass			Right Hand			
8	8272618	Insulation, Door		8523165	Black			
				8523166	White			
				8523167	Biscuit			
				W10113925	Universal Silver			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	W10138079	Rack, Oven (2)
2	9761031	Drawer, Storage
3	3196817	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196815	Almond
	3196813	Black
5		Panel, Drawer Frnt
	W10022090	White
	W10022110	Biscuit
	W10022100	Black
6	8053334	Spacer, Glide
7	9755797	Panel, Stnls & US
8	3196168	Screw
9		Handle, Door
	9757219	Stainless Model
	9762251	Universal Silver
10	9781235	Clip, Stnls, Unv Slv
11	W10031790	Screw, Universal Silver and Stainless Steel Models

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: SF362LXTB2, SF362LXTQ2, SF362LXTT2, SF362LXTS2, SF362LXTY2
(Black)(Designer White)(Designer Biscuit)(Stainless Steel)(Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			INSULATION			ACCESSORY PARTS		
<u>SPLICING WIRES--25FT. LENGTH</u>			261514 Insulation, Fiberglass (1-1/2" x 24" x 120")			241430 Foil, Aluminum Oven (18" x 25')		
242828 Wire, Black 12 Ga. 150° c			240132 Insulation, Fiberglass (2-1/2" x 22" x 120")			4396923 Pan – Broiler		
242821 Wire, Blue 14 Ga. 150°c			<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>ANTI-TIP KIT</u>		
242822 Wire, Brown 14 Ga. 150°c			72017 White			W10017440 Anti-Tip Kit		
242830 Wire, Brown 14 Ga. 200°c			4392899 Biscuit			<u>WIRING HARNESS PARTS</u>		
242823 Wire, Green 14 Ga. 150°c			511873 White Porcelain (2 Oz.)			W10082160 Harness, Main (EOC Pyro)		
242824 Wire, Orange 14 Ga. 150°c			<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>			8524207 Harness, Wire Bake/Broil		
242825 Wire, Red 14 Ga. 150°c			350930 White			8523599 Harness, Wire (Cooktop Spark)		
242831 Wire, Red 14 Ga. 200°c			4392901 Biscuit			W10045060 Harness, Wire (Ground)		
<u>REFINISHING MATERIAL</u>			285006 Superior Black			3196896 Clip, Wire		
242756 Touch-Up Self-Clean(1/2 Pt)			206922 Primer (White)			3400964 Clip, Wire		
261582 Grease			<u>PAINT, BULK (1 qt.)</u>			313438 Clip, Harness		
			799344 White (Uncut)			3196173 Screw		
			4392900 Biscuit (Uncut)			3196696 Clip, Harness		
						3196174 Screw-Grnd Harns		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST